

**DETERMINATION OF DRY MATERIAL CONTENT OF ADMIXTURE**  
**(As Per IS 9103:1999- RA 2018)**

Lab Job No.: \_\_\_\_\_

DATE: (i) Sample Received: \_\_\_\_\_

Sample Code No: \_\_\_\_\_

(ii) Sample Tested: \_\_\_\_\_

Lab Temp: \_\_\_\_\_

Sr. No.	Weight of bottle and Sand	Weight of bottle, Sand and Sample	Weight of bottle, Sand and Dry Material	% Residue of Drying = $\frac{W_3 - W_1}{W_2 - W_1} \times 100$
	W <sub>1</sub> (g)	W <sub>2</sub> (g)	W <sub>3</sub> (g)	

Average Dry % .....

Tested by

Verified by